

## Door Lock instructions

The door is opened by electronic code. The keypad is normally dark. Touch the Yale circle on the top center of the pad with one finger and it will light up. Enter your code followed by the check mark ✓ on the bottom right. The lock will open. It will remain unlocked for 30 seconds, then relocks automatically.

If you still can't get in, call Jerry. He can open the door remotely.

